



- RR2149 Pneumatic Black Face
- RR2225 Pneumatic White Face
- RR2191 Electric Black Face
- RR2229 Electric White Face



- RR2145 Pneumatic Black Face
- RR2241 Pneumatic White Face
- RR2188 Electric Black Face
- RR2260 Electric White Face

Pneumatic (Use with tank) Electric (Use without tank)

RR9074 PNEUMATIC SWITCH ONLY
RR9039 ELECTRIC SWITCH ONLY



RR2158 Single Gauge



RR2178 Dual Gauge



RR2097 Single Gauge



RR2219 Dual Gauge

IN CAB SYSTEM

Utilizes a **standard duty 9284** compressor and gauge for moderate usage of your air helper springs.

IN CAB SYSTEM

Utilizes a **heavy duty 9285** compressor, providing equal inflation of both air springs.



RR2334 Remote Air Command I

The Remote Air Command I provides an instant air source, using the 9284 compressor, for any air helper spring system, leveling the vehicle remotely from up to 50 ft. away. There's no air line to route through the firewall, no gauges or switches to mount on the dash, with a compact design for easy installation.



RR2340 Remote Air Command II

The Remote Air Command II provides an instant air source, using the 9285 compressor, for any air helper spring system, leveling the vehicle remotely from up to 50 ft. away. There's no air line to route through the firewall, no gauges or switches to mount on the dash, with a compact design for easy installation.



Standard Duty Compressor

RR9284

(up to 1 gallon air tank)
130 PSI MAX



Heavy Duty Compressor

RR9285

(up to 3 gallon air tank)
1/8" NPT
150 PSI MAX



RR2168 HD 1/2 Gal Tank

IN CAB SYSTEM

Utilizes a **heavy duty 9285** compressor, providing equal inflation of both air springs.



RR2047 1/2 Gal Tank 9124

RR2232 1 Gal Tank 9125

RR2239 3 Gal Tank 9127

TANK SYSTEM w/9285

The kit offers an on board air source for inflating air springs, tires or other inflatable items. This unit is hard mounted to the vehicle and offers a wide variety of uses.



AIRTANKS

RR9124 (1/2 Gallon)

RR9125 (1 Gallon)

RR9126 (2 Gallon)

RR9127 (3 Gallon)